PERSONAL PROTECTIVE EQUIPMENTS (P.P.E.) AND ACCESSORIES

ANCHOR AND FIXING TESTER

On top of its anchorage range, GM Distribution provides you a tension tester to control easily and quickly the resistance of anchors on building sites.



The extractometer is a portable system allowing you to test anchors.

It is used to confirm the resistance of anchors in most construction materials. This device is essential to validate the compliance of the anchorage system with EN795 standards.

- " The installer shall check the suitability (with the considered material) applying on all structural anchors:
- an axial tensile load of 5KN to check the strength of the fixing.

The structural anchor should hold up the load for at least 15 seconds."





- Simple and quick setting up.
- Light and handling ability thanks to its carrying handle.
- Reading on a pointer indicator with peak value.
- Packaged in a transport case with a set of accessories for all types of fixing.